

YELLOWSTONE SEVEN DEPARTURE



DEPARTURE ROUTE DESCRIPTION

TAKEOFF ALL RUNWAYS: Fly assigned heading and altitude for RADAR vectors to assigned transition. Expect filed altitude 10 minutes after departure.

LOST COMMUNICATIONS: If no transmissions are received within one minute after departure, maintain assigned heading until 7000 feet, then climb to filed altitude via direct DEN VOR/DME, thence via assigned transition. If filed altitude is above 10000 feet, cross DEN VOR/DME at or above 11000 feet.

CHEYENNE TRANSITION (YELLOW7.CYS): From over DEN VOR/DME via DEN R-349 and CYS R-163 to CYS VORTAC.

HANKI TRANSITION (YELLOW7.HANKI): From over DEN VOR/DME via DEN R-015 and GLL R-034 to HANKI INT.

LARAMIE TRANSITION (YELLOW7.LAR): From over DEN VOR/DME via DEN R-334 and LAR R-125 to LAR VOR/DME.

MEDICINE BOW TRANSITION (YELLOW7.MBW): From over DEN VOR/DME via DEN R-334 and MBW R-133 to MBW VOR/DME.

NATTI TRANSITION (YELLOW7.NATTI): From over DEN VOR/DME via DEN R-334 and LAR R-125 to LAR VOR/DME, then via LAR R-273 to NATTI INT.

RAPID CITY TRANSITION (YELLOW7.RAP): From over DEN VOR/DME via DEN R-359 and GLL R-174 to GLL VOR/DME, then via GLL R-005 and RAP R-186 to RAP VORTAC.

SCOTTSBLUFF TRANSITION (YELLOW7.BFF): From over DEN VOR/DME via DEN R-015 and BFF R-191 to BFF VORTAC.

SW-1, 26 JUN 2014 to 24 JUL 2014

SW-1, 26 JUN 2014 to 24 JUL 2014